


IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed including the following.

Number of Modules	Power(w)	Dimension(mm) [High Bay Light/ Flood Light/ Tunnel Light]	Weight(kg) [High Bay Light/ Flood Light/ Tunnel Light]
1	40/50/60	166*270*165/ 166*270*190/ 166*270*165	2.3/ 2.4/ 2.3
2	80/100/120	239*270*165/ 239*270*227/ 239*270*165	3.5/ 3.6/ 3.5
3	120/150/180	312*270*165/ 312*270*263/ 312*270*165	4.4/ 4.6/ 4.4
4	160/200/240	385*270*165/ 385*270*300/ 385*270*165	5.2/ 5.4/ 5.2
5	200/240	458*270*165/ 458*270*336/ --	6.1/ 6.3/--
6	240	531*270*165/ 531*270* 373/ --	6.8/ 7.1/ --



100-240V/277V AC, 50/60Hz, Suitable for Wet Locations (IP66), Class I

*This product must be grounding



Tighten bracket screws on both sides, luminaire installation angle will be fixed by the lock gear.



TO INSTALL:



*1 Minimum M10 (3/8") Bolts (not-provided)


*2 Mounting Nuts are not provided

*3 Allen Wrench: 8mm (5/16")



*1 Pendant Stem can not be the soft material (not-provided)

*2 Look Nuts are not provided



STANDARD MOUNTING (High Bay Lights)

STEP 1:

Assemble the mounting bracket to the fixture by provided M10 (3/8") round head screws.

STEP 2:

Attach Lock-Nut(A) to the bottom of the Pendant Stem. Attach Lock-Nut(B) by holding the interjacent Fixture Bracket and tightening Lock-Nut(B) until secure. See **Figure 4**.


STEP 3:

Loosen the mounting bracket screws, adjust the fixture to desire position, re-secure the screws.


STEP 4:

Connect the **Power Cord** to the supply wiring per "**Electrical Connections**" section for completing electrical connections.


Support height (Floodlights)




1 Module




2 Modules




3 Modules




4 Modules




5 Modules



6 Modules



- *1 Allen wrench: 8mm(5/16")
 *2 Minimum M10(3/8") screws (Not provided)
 *3 Screw nuts (Not provided)



STANDARD MOUNTING (Floodlights)


STEP 1:

Use an Allen wrench to fix the body and the support (is not necessary to tighten the screws too hard). Align support and built-in fitting, tighten the screws as **Figure6**.


Align support and built-in fitting, tighten the screws as **Figure7**.

STEP 2:

Settle in the adequate angle position and use Allen screw to fix it as **Figure8**. Connect wire.



- *1 Allen Wrench: 8mm (5/16")
 *2 Minimum M10 (3/8") Bolts (not-provided)
 *3 Mounting Nuts are not provided



STANDARD MOUNTING (Tunnel Lights)

STEP 1:

Adjust first the bracket position, to a needed installation angle, then use the wrench to fix the bracket, as shown in **Figure9**.

STEP 2:


Hold up the fixture, align the screw holes of the fixture and the installation bridge, as shown in **Figure10**.

STEP 3:


Use tool to tighten the screws on the bracket, as shown in **Figure11**.

STEP 4:

The corresponding connection, as shown in **Figure12**.



- *1 Lock Nuts are not provided
 *2 Customize the Mounting board according to actual requirements.



IMPORTANT

Check whether it concerns an AC(Alternating Current) based system - 100-240V/277V AC, 50/60Hz.

ELECTRICAL CONNECTIONS - 100-240V/277V AC, 50/60Hz

PHASE TO NEUTRAL WIRING

AC BASED

STEP 1:

Make the following Electrical Connections:

- Connect **INPUT GROUND** conductor to **GREEN WIRE** position of the terminal block or GROUND conductor of LED driver.
- Connect **INPUT VOLTAGE** conductor to **BROWN WIRE** position of the terminal block or LIVE conductor of LED driver.
- Connect **INPUT NEUTRAL** conductor to **BLUE WIRE** position of the terminal block or NEUTRAL conductor of LED driver.


STEP 2:

Make sure all the connection are correct.

STEP 3:

If the fixture without a terminal block, please insulate all electrical connections with wire nuts suitable for at least 90°C.

Input cable should be at least H05RN-F 3x1.0mm²(SJTW 18AWG) or outdoor grade cable with rubber sheathed(not supplied). The cable must have a minimum cross sectional area of 1.0mm²(18AWG).



- To avoid the possibility of electrical shock, turn off power supply before installation or servicing. Installation and servicing should be performed by qualified personnel.
- Product must be installed in accordance with your local electrical code. If you are not familiar with these codes and requirements, consult a qualified electrician.
- Do not change the structure or any components of the fixture to ensure safety.
- Lock the installation angle after luminaire installed. As following figure.

*If the fixture with built-in 3 in 1 dimming function, please connect INPUT POSITIVE(+) signal conductor to DIM+ (BLUE WIRE), INPUT NEGATIVE(-) signal conductor to DIM-(WHITE WIRE) of LED driver.

*The junction box should have the same electrical hazard protection grade and IP rating with the luminaire.